



P-22013

## **SLIPFORM JACK 604-SBU (01-JR61)**

***Web version manual***

For complete version  
contact Bygging-Uddemann:  
[info@bygging-uddemann.se](mailto:info@bygging-uddemann.se)



## ***TABLE OF CONTENTS***

- 1. Brief specification**
- 2. Application**
- 3. Principal components**
- 4. Description**
- 5. Mode of operation**
- 6. Operating instructions**
- 7. Maintenance**
- 8. Releasing of jack teeth**
- 9. Recovering of climb tubes**
- 9. Level control guide**
- 10. Part List**



## **1. BRIEF SPECIFICATION**

- 1.1 Lifting capacity 6 tons.**
- 1.2 Lifting stroke 25 mm.**
- 1.3 Piston area 62,6 sq.cm.**
- 1.4 Swept volume 0,157 litres.**
- 1.5 Working hydraulic pressure 100 bar.**
- 1.6 To be operated with pump type: HP 17.160 G.**
- 1.7 Jack tube 33,7 mm dia.**

## **2. APPLICATION**

- 2.1 Lifting of slipforms when stepwise recovery of the climb tube is needed.**

Lifting of temporary or permanent structures in combination with slipforms (e.g. roof steelwork).

## **3. PRINCIPLE COMPONENTS**

- 3.1 Level control guide (08-0004)**
- 3.2 Hydraulic cylinder (02-JC04)**



- 3.3      **Jack casing (02-0072)**
  
- 3.4      **Movable jaw casing (02-0065)**
  
- 3.5      **Fixed jaw casing (02-GR02)**
  
- 3.6      **Lifting collar (02-0075)**
  
- 3.7      **Releasing device. (70-1734)**

***Web version manual***

For complete version  
contact Bygging-Uddemann:  
[info@bygging-uddemann.se](mailto:info@bygging-uddemann.se)